

### Settings

Username: For FTP Login Password: For FTP Login

FTP Site: FTP IP ADDRESS Port 21

Time for next Slide: How long each slide will appear on the screen.

Site images: See advanced Folder setup.

URL found: If index.php or index.html where found in the brand folder.

URL to image: converts the index.php or index.html to a image file in the images share to be

part of the slide show this URL will be refreshed every 10 mins.

#### Network

Setup WIFI setting and host name if you have more then one Whitbox on locations.

## Overscan

If you have a black margin around the images on the screen change this setting.

#### Rotation

If the display is not in the normal upright setting, this setting can be changed.

## Update

Will update any change made, pending will change to OK if there are no errors And a reboot is normally required.

## Update Nightly Reboot.

Time is currently static coded from core image.

Setup a nightly reboot of the Nightly Reboot. This is when the WHIT box will update the images found in the network share.

Folder setup

Basic:

SMB:

\\ServerXX\Sharename X:\data\sharename

FTP:

Username:UUUUU Password: UUUUU Home folder

X:\data\Sharename

Advanced

SMB:

\\Serverxx\Sharename\whitbox1 \\Serverxx\Sharename\whitbox2

# FTP IE:

username:whitbox1 home folder x:\data\sharename username:whitbox2 home folder x:\data\sharename Check the box for URL to Image.